



How to replace the fascia

Step 1: Take out the bolts as the picture shows on.



Step 2: Take out the bolts as the picture shows on.





Step 3: Gently draw the fascia out as the following image shows.



Step 4: Take out all the knobs.



Step 5: Remove all screws from the knob bezel.



Step 6: Take out all the knob light connection end.




Step 7: Separate the rear burner ignition wire as the picture shows.



Step 8: Loosen the ignition box as the picture shows.



Step 9: Separate the knob light line as the picture shows.




Step 10: Loosen the knob light switch as the picture shows.





Step 11: Replace with a new fascia.



Step 12: Reverse steps above to install the parts back. Please pay attention when installing the fascia, since each injector on the manifold must aim at the burner inlets.

